

VEF TA-202

INTRODUCTION

This manual is made in order to familiarize you with your phone set. To get maximum benefits of this product, we suggest you to read the User's Manual carefully before using your phone set.

FEATURES

Last number redial
Flash
Pause
MUTE
P-T fast switch
Pulse/Tone dialing mode
Ringer volume adjustment
Desktop/Wall Mounting.

INSTALLATION

Plug line cord into jack at the rear of the telephone base, connect the other end of the line cord to telephone line. Connect the base and the handset with coiled cord. Set ringer volume according to your personal preference. Set the P/T switch as required for your telephone exchange.

ANSWERING CALLS

Pick up the handset after ringing. When finished, return the handset to the cradle on the base.

MAKING CALLS

Lift the handset, listen to the dial tone and dial out the desired number. After finished return the handset to the cradle on the base.

RINGER VOLUME ADJUSTMENT

Slide the ringer switch to RING to choose the ringer volume according to personal preference.

P/T MODE ADJUSTMENT

Slide the switch to P/T position to select PULSE or TONE dialing mode

FLASH

Pressing this button will disconnect the phone from the line and give the dial tone again. Flash is used for many operations in EPABX.

REDIAL

Pressing this button will redial the last number you dialed.

PAUSE

Pressing this button will insert a time gap of 3.6s between two digits.

MUTE

Pressing this button will deactivate the microphone of handset during the conversation. You can talk freely without caller hearing you. Press this button again if you want to resume your conversation.

P-T

When put the P-T switch on the Pulse mode, Pressing this button will make the dialing to be TONE dialing.

PARTS CHECKING LIST

User's Manual Base Handset Straight Line Cord Coiled Cord