

USER'S MANUAL VEF TA-211

FEATURE LIST:

- Last Number Redial.
- Flash Button.
- Pause Button.
- Tone/pulse switch.
- Ringer Volume Control.
- Ringer Indicator.

INSTALLATION

1. Connect one end of coiled cord to the jack of handset, connect the other end to the jack of base set.
2. Plug one end of flat cable to line jack of this phone, plug the other end to wall jack.

OPERATION

RINGER HI/LO SWITCHABLE

Select the desired function of the tone ringer.

HI.... Normal setting rings on incoming calls.

LO.... The ringer sound level will be cut down.

TONE/PULSE DIALING MODE SELECTION

You can choose the type of dialing by selecting TONE/PULSE mode.

MAKING CALLS AS A NORMAL TELEPHONE

1. Pick up the handset.
2. Dial the number you want to call.

RECEIVING CALLS AS A NORMAL TELEPHONE

1. When your phone rings, simply pick up the handset and speak into the mouthpiece of the handset.
2. Hang up the handset on the Base unit to release the telephone line when conversation is completed.

LAST NUMBER REDIALING

1. Pick up the handset and you hear a dial tone.
2. Press REDIAL button the last number will be automatically redialed.

FLASH FUNCTION

The Flash button replaces the hook switch when using features such as call waiting and call forwarding.

PAUSE FUNCTION

To dial a number from an automatic switch board system (PABX), you must first dial an access code. Then pause a few second to wait for an outside line. The "PAUSE" key stores a 2-3 seconds pause to give the automatic switchboard time to find available outside line.